

TO OPERATE PLEASE READ INSTRUCTIONS



KEY FOR SEATBELT

SEATBELT

LOCKING CHAINS



USE KEY TO RELEASE ON/OFF DEVICE



UNLOCK AND LIFT UNTIL FREE OF SWING THEN LOWER TO GROUND